

用户手册

SG-289

蓝牙 GPS 接收器 暨轨迹记录仪 V1.7



台湾制造 2009/01/08

www.dagamagps.com

免费服务热线(限中国大陆): 400-820-1322

service@dagamagps.com



目 录

1. 介	绍	3
1.1	概述	3
1.2	· 品特点 3	3
1.3	技术参数	4
2. 硬	件	5
2.1	尺寸 5	5
2.2	配件	5
2.3	产品描述	6
3. 使周	月方法11	1
3.1	开始1:	1
3.2	引GPSViewer软件测试产品12	2
3.3	功能 13	3
3.4	寻航13	3
3.5	数据应用13	,
4. 售	后服务条例10	6
附录:	软件规格1	7
附录:	时区表20	6



1. 介绍

1.1 概述

SG-289 GPS接收器暨轨迹记录仪带有LCD显示屏并支持蓝牙数据传输,是一款整合了蓝牙、UART接口及内置可充电锂电池的高性能一体化GPS解决方案。

SG-289 接收器采用包含无线蓝牙模块、高灵敏度且性能优异的SiRF III GPS芯片及可充电锂电池集成式设计。SiRF Star III 芯片具有极高的GPS信号接收及跟踪灵敏度。本蓝牙GPS接收器可帮您实现在手持移动设备上接收GPS数据或借助SD/MMC卡直接保存GPS定位数据,也可以通过专用数据线连接PC机之类的设备进行数据同步传输。借助蓝牙无线传输技术,您可以将接收器放置在GPS信号最好的位置。接收器内置了便携、可充电、可更换的锂电池,像手机一样。使用此设备的唯一的要求就是您的手持设备必须也要具有蓝牙功能。此接收器非常适合用于车辆导航、测图、安防及农业等应用。只要具有开阔的GPS信号接收视野和电源即可工作。由于采用了低功耗的技术,接收器可同时跟踪接收20颗卫星并且具有极快的TTFF(首次定位时间)、重捕获小于1秒(平均值),数据更新时间为1秒1次。该设备采用SD/MMC卡存储TXT格式数据文件。

1.2 产品特点

SG-289 功能多样、技术领先,方便整合、易于使用。

- 1. 采用 SiRF StarⅢ 高灵敏度GPS接收芯片。
- 2. 高灵敏度同时跟踪多达 20 颗卫星。
- 3. 快速信号接收, 芯片内建 200,000 个相关器。
- 4. 支持WAAS/EGNOS/MSAS差分信号接收。
- 5. 借助高灵敏度的信号处理软件,可在城市、峡谷及树下等环境中实现快速定位及重捕获。
- 6. 内置大容量可充电锂电池,超长使用时间。
- 7. 电池温度过高保护功能。
- 8. 通过SPP协议兼容蓝牙设备。
- 9. 内置高性能GPS接收天线。
- 10.3色LED灯,指示蓝牙,GPS和电池状态。
- 11. LCD屏幕显示时间、经纬度及高度等信息。
- 12. 支持SD/MMC卡,存储TXT格式的数据文件,最大支持容量2G(文件系统格式为FAT,推荐使用Sandisk晟碟及Transcend创见之正品)。
- 13. 支持标准 NMEA-0183 数据协议和SiRF二进制码(波特率19200)。
- 14. 内置备份电池,用于实现存储数据、可供RTC持续工作及缩短TTFF。
- 15. 基于Flash的程序存储技术,可通过串口更新软件。
- 16. 紧凑型的高集成度的设计方案,适合于各种便携式应用。





1.3 技术参数

概述

频率 L1, 1575.42 MHz

C/A 码1.023 MHz通道数20 通道天线内置

灵敏度

获取 -159 dBm (典型值)

精度

位置 正常定位 5-25 m, 无 SA 干扰

垂直精度<5 m, WAAS/EGNOS 修正后(95%) 水平精度<2 m, WAAS/EGNOS 修正后(95%)

时间 1 微妙(与 GPS 时间同步后)

坐标系统

默认 WGS-84

定位速度 (开阔天空)

热启动1 s, 平均值温启动38 s, 平均值冷启动42 s, 平均值再捕获0.1 s, 平均值

动态

高度 < 18,000 m (60,000 英尺) 速度 < 515 m/s (1,000 节)

加速度 <4G

GPS 协议

协议语句 NMEA-0183

默认 NMEA GGA, GSA, GSV, RMC, 19200 波特率(GLL, VTG, ZDA 可

选)

8 位数据位,1 位停止位,无校验码

蓝牙特性

蓝牙协议标准 1.1 版


发射功率 Class 2 (最大 4 dBm) 接收灵敏度 -80 dBm (误码率<0.1%)

作用距离 10 m (典型值)

通信协议 标准蓝牙通信协议 (SPP)

功耗

输入电压 5.0 ± 5% V, 直流





工作电流 75mA(正常模式下平均值)

电池

电源 大容量可充电、可更换锂电池(充电电压: 5V DC)

充电时间 2.5 小时(典型值)

工作时间 12 小时(充满电、连续跟踪工作模式)

环境特性

工作温度 $-10 \, ^{\circ}\text{C} \sim +60 \, ^{\circ}\text{C}$ 存储温度 $-20 \, ^{\circ}\text{C} \sim +70 \, ^{\circ}\text{C}$ 充电温度 $0 \, ^{\circ}\text{C} \sim +45 \, ^{\circ}\text{C}$

工作湿度 5%~95%, 无冷凝

尺寸 93.1 mm (长) x 45.7 mm (宽) x 22.8 mm (高)

重量 <70 g (不含电池和 SD/MMC 卡)

2. 硬件

2.1 尺寸

该接收器尺寸为: 93.1 mm (长) x 45.7 mm (宽) x 22.8 mm (高)

2.2 配件

- 1, 一块大容量可充电锂电池
- 2, 一个车载点烟器电源适配器
- 3、 一个室内交流电电源适配器
- 4, 一根 USB 电缆线
- 5、数据通讯专用 USB 电缆线(可选)
- 6, 保修卡
- 7, 测试软件及使用手册 CD






2.3 产品描述


1, 机器如下图所示。






机器正面有3个LED指示灯,分别指示GPS、蓝牙和电池状态。一个LCD显示屏指示时间、经纬度、高度、速度、电源状态、SD/MMC及卫星信号状态。详细的LED和LCD 指示说明在下一节中介绍。电源开关和SD/MMC卡插槽在机身的侧面。Mini USB接口(充电用)在机身的底部。

2, LED 指示状态说明




配对状态: 0.2秒闪烁一次已经连接: 1 秒闪烁一次待机状态: 3 秒闪烁一次




接收状态:常亮定位状态:闪烁






低电量时: 红灯闪烁 正常状态: 红灯熄灭



充电状态: 绿灯常亮 充电暂停: 绿灯闪烁 正常状态: 绿灯熄灭

备注: 电池充电暂停时(充电超时或电池过热)请拔掉电源线等候一会再继续充电。


3, LCD 指示说明 显示屏显示以下信息:






白色图标指示 SD/MMC卡未插入


黑色图标指示 SD/MMC卡已插入






① 请在打开设备电源前插入一张 SD 或 MMC 卡至卡槽中。记录过程中切勿拔出存储卡! 拔出前请先 关闭电源。SD/MMC卡应被提前格式化成 FAT 格式。请勿选择 NTFS或 FAT32文件系统。

- 4, 蓝牙/背光 使用 (默认都为 打开)
 - 1)在正常使用状态下, 按住按钮 "A" 1 秒钟后释放可以关闭或打开背光。
 - 2)参考以下"5. 显示设置"章节关闭或打开蓝牙。
- 5, 显示设置 (请参考 附录: 时区表 以进行时区调整)
 - 1. 按住按钮 "A" 2秒钟然后释放可进入设置菜单。
 - 2. 按住按钮 "Select" 1秒钟然后释放可以增加参数数字。
 - 3. 按住按钮 "Next" 1秒钟然后释放可以选择不同的参数。
 - 4. 完成设置后,按住按钮 "Exit" 1秒钟然后释放可以返回正常使用状态。



时区设置:

-13~+13, 按住"Select"按钮, 每次数字加1数字范围为-13~+13




报警速度设置


40-125, 按住"Select"按钮, 每次数字加5

当超速时背光灯闪烁 数字范围为40-125






速度单位设置: Km/h, Mi/h, Knot



蓝牙设置: 开、关




退出: 回到正常使用状态


- 6, SD/MMC记录器设置 (默认记录模式为 速度)
 - 1. 按住按钮 "B" 2秒钟然后释放可进入 SD/MMC 记录器设置菜单。
 - 2. 按住按钮 "Select" 1秒钟然后释放可以增大参数数字。
 - 3. 按住按钮 "Next" 1秒钟然后释放可以选择不同的参数。
 - 4. 在 POI 模式下,蓝牙开关功能禁用。按住按钮 "B" 1秒钟然后释放即可记录一个数据,每次按下将仅记录一次数据。
 - 5. 在 速度 模式下,记录方式说明如下:

速度	记录方式
0 Km/h	20秒钟记录一次数据
小于10 Km/h	2秒钟记录一次数据
小于40 Km/h	5秒钟记录一次数据
小于 70 Km/h	8秒钟记录一次数据
小于100 Km/h	10秒钟记录一次数据
超过100 Km/h	20秒钟记录一次数据





NMEA 设置: GGA, RMC, GGA RMC




时间间隔设置: 熔件"Salast"进行

按住"Select"进行更改,数字 范围为3-55 只在时间模式下有效 每次时间间隔记录一次数据




记录模式设置:

关闭, 时间,速度,P0I 默认为"速度"



记录序号:


显示从开机到现在已记录的数据数量 (GGA或RMC每次记录一行 GGA RMC 每次记录两行)



显示记录:

Yes, NO

选择Yes:显示已记录数据数量 选择NO:不显示已记录数据数量




选项设置:

按 "Select" 按钮进行设置 COURSE: 显示方位角

COURSE: 显示方位角 SPEED: 显示速度___

请参考2.3.3LCD屏幕指示






退出: 回到正常使用状态

3. 使用方法

3.1 开始

第 1 步: 安装电池

- (a) 将电源开关推到 "OFF" 位置
- (b) 按住 "PUSH" 按钮然后推动后盖将其取下
- (c) 将锂电池放入电池槽,注意电池的方向
- (d) 推动后盖至锁住位置



第 2 步: 充电


首次使用时请将电池充满电。连接配件中的充电设备至mini USB接口,如下图所示。



电源指示灯是双色LED灯。充电时,绿色LED灯常亮直至充电完成。电源指示灯的各种含义如下:

低电量 ------- **红色LED** 闪烁 充电中 ------ **绿色LED** 常亮

充电暂停 (充电时间过长或者电池过热保护) ----- 绿色LED 闪烁






备注:正常充电时,如发现设备绿灯不常亮,一般并非设备故障;此时,请不要断开充电器,打开电池盖后直接取出电池,此时电源指示灯变为绿色并慢速闪烁,待闪烁5次后将电池重新放入电池仓,再等待少许时间即可正常充电!

敬告:电池红灯亮的时候请务必充电,如果电池放尽可能发生无法充电的情况!由于锂电子的特性,建议不要过充过放,最好是在关机状态下充电2~3小时即可,不提倡在开机状态下充电(由于该电池具有热保护功能,所以开机状态下持续充电可能会自动暂停,出现绿灯闪烁的情形)。

第 3 步: GPS 信号接收

电源开关推到 "on", 开关位于机身的侧面。电源打开后, 蓝牙和GPS指示LED灯都会开始闪烁。



将蓝牙GPS接收器放置在天空开阔的地方。红色LED 指示以下状态:

- (a) LED 常亮, 电源接通开始接收卫星信号;
- (b) LED 每秒钟亮1次然后灭1秒,接收器开始输出定位数据。

第 4 步: 建立蓝牙无线连接

打开主设备,带有蓝牙功能的一部PDA或者笔记本电脑。然后打开蓝牙管理程序,执行搜索并匹配。 主设备连接蓝牙GPS的默认PIN码是 "0000"(配对模式)。

蓝色LED 指示以下蓝牙状态:

- (a) LED 3秒钟闪烁一次, 待机状态:
- (b) LED 0.2秒闪烁一次,配对模式:
- (c) LED 1秒钟闪烁一次, 蓝牙已经连接。

①正常使用过程中,为了避免更新 SD/MMC 卡存储文件失败,建议每次关机后再开机的时间间隔须在 5 秒钟以上!

3.2 用GPS Viewer软件测试产品

在主设备上安装GPS Viewer软件。然后您就可以随时查看GPS接收器的工作状态了。以下是操作步骤:

- (a) 运行 Viewer 程序,点击 "Com Port."按钮进行通信端口设置,"Com Port"选择用于无线连接的端口号,波特率可以选择 2400,4800,9600,19200,38400...
- (b) 点击 "Start" 开始接收数据,通常情况下,一个窗口显示NMEA格式数据流,另一个窗口显示卫星信号质量。
- (c) 一旦无线连接成功,点击 "Stop" 按钮可以中止程序。此外,您还可以点击诸如 "Cold Start" 按 钮以进行相应的冷启动测试等。





3.3 功能

电源打开后,SG-289 蓝牙GPS接收器即马上开始卫星信号跟踪接收过程及蓝牙无线连接工作。正常环境下,42秒(平均值)可以完成首次定位过程。定位后,相关的定位信息——有效位置、速度及时间将通过输出通道对外传输。SG-289 蓝牙GPS接收器利用各种原始数据,如上次定位点位置、日期、时间及卫星轨道数据等可以实现最优异的性能。如果在原始数据中存在重大误差或卫星轨道数据过期,可能需要更多时间才能定位。

3.4 导航

定位完成后,SG-289 蓝牙GPS接收器将通过输出通道对外发送有效的可用于导航的位置信息。包括:

- 1) 纬度/经度/高度
- 2) 速度
- 3) 日期/时间
- 4) 卫星和接收器状态

3.5 数据应用


该设备使用SD或MMC卡存储TXT格式的数据,保存下来的数据可做以下用途:

- 1. 将这些数据保存在电脑中,可直接打开查看 GPS 信息,如经纬度、速度、高度、日期和时间等。
- 2. 使用 GPS Viewer 软件的演示模式重播这些文本格式的数据。
 - 2.1 打开 GPS Viewer
 - 2.2 选择演示模式
 - 2.3 设置演示速度
 - 2.4 按 "Start" 按钮选择数据






2.5 下图为数据重播演示界面。



- 3. 使用 Google Earth 查看路线轨迹。
 - 3.1 请搜索 Google 网站,下载并安装 Google Earth 软件(免费),如下图所示:








3.2 将 txt 格式的数据文件转换成 Google Earth 支持的 KML 格式,下图为转换示例:







- 3.3 用 Google Earth 打开转换后的文件。
- 3.4 下图展示了一条行进轨迹及其时间。



4. 售后服务条例

此 GPS 接收器具有 1 年免费保修期(自购买之日起算),在保修期内,任何品质及功能方面的故障都可以享受免费保修服务。自购买之日起 15 日内到我公司网站进行注册,可获得延长保修期 90 天的免费增值服务。

出现以下情况时售后服务条例失效:

- 1. 产品序列号标签脱落、损坏或被修改。
- 2. 由意外事故、不正确的使用方法、用户疏忽、火灾、洪灾、闪电或其他自然因素、未经授权的 更改及未遵循随机的使用说明书导致的产品损害、性能衰退或故障。
- 3. 任何未经 Dagama 授权的维修或尝试维修行为。
- 4. 使用未经 Dagama 认可的配件。



附录:软件规格

NMEA Protocol

The SG-289 interface protocol is based on the National Marine Electronics Association (NMEA) interface specification, namely, the NMEA 0183 standard. The SG-289 is capable of supporting the following NMEA message formats specifically developed and defined by SiRF.

NMEA Message Prefix	Format	Direction
\$GPGGA	Time, position and fix type data.	Out
\$GPGLL	Latitude, longitude, time of position fix and status.	Out
\$GPGSA	GNSS DOP and active satellites	Out
\$GPGSV	Satellites in view.	Out
\$GPMSS	Radio beacon signal-to-noise ratio, signal strength, frequency, etc.	Out
\$GPRMC	Recommended minimum specific GNSS data.	Out
\$GPVTG	Speed and course over ground.	Out
\$GPZDA	Date and time.	Out

General NMEA Format

The general NMEA format consists of an ASCII string commencing with a '\$' character and terminating with a <CR><LF> sequence. NMEA standard messages commence with 'GP' then a 3-letter message identifier. The message header is followed by a comma delimited list of fields optionally terminated with a checksum consisting of an asterix '*' and a 2 digit hex value representing the checksum. There is no comma preceding the checksum field. When present, the checksum is calculated as a bitwise exclusive of the characters between the '\$' and '*'. As an ASCII representation, the number of digits in each number will vary depending on the number and precision, hence the record length will vary. Certain fields may be omitted if they are not used, in which case the field position is reserved using commas to ensure correct interpretation of subsequent fields.



\$GPGGA

This message transfers global positioning system fix data. Following is an example.

\$GPGGA,161229.487,3723.2475,N,12158.3416,W,1,07,1.0,9.0,M,,,,0000*18

The \$GPGGA message structure is shown below:

Field	Example	Unit	Notes	
Message ID	\$GPGGA		GGA protocol header.	
UTC Time	161229.487		hhmmss.sss	
Latitude	3723.2475		ddmm.mmmm	
N/S Indicator	N		N=north or S=south.	
Longitude	12158.3416		dddmm.mmmm	
E/W indicator	W		E=east or W=west.	
Position Fix Indictor	1		 0: Fix not available or invalid. 1: GPS SPS mode, fix valid. 2: Differ. GPS, SPS mode, fix valid 3-5: Not supported. 6: Dead Reckoning Mode, fix valid. (1) 	
Satellites Used	07		Number of satellites used to calculate fix. Range 0 to 12.	
HDOP	1.0		Horizontal Dilution of Precision.	
MSL Altitude (2)	9.0	Meter	Altitude above mean seal level.	
Units	M	Meter	M stands for "meters".	
Geoid Separation (2)		Meter	Separation from Geoids can be blank.	
Units		Meter	M stands for "meters".	
Age of Diff. Corr.		Second	Age in seconds. Blank (Null) fields when DGPS is not used.	
Diff Ref. Station ID	0000			
Checksum	*18			
<cr> <lf></lf></cr>			Message terminator.	

⁽¹⁾ Only apply to NMEA version 2.3 (and later) in this NMEA message description.

⁽²⁾ SiRF does not support geoid corrections. Values are WGS84 ellipsoid heights.



\$GPGLL

This message transfers geographic position, latitude, longitude, and time. Following is an example.

\$GPGLL,3723.2475,N,12158.3416,W,161229.487,A,A*41

The \$GPGLL message structure is shown below:

Field	Example	Unit	Notes	
Message ID	\$GPGLL		GLL protocol header.	
Latitude	3723.2475		ddmm.mmmm	
N/S Indicator	N		N=north or S=south.	
Longitude	12158.3416		dddmm.mmmm	
E/W indicator	W		E=east or W=west.	
UTC Time	161229.487		hhmmss.sss	
Status	A		A: Data valid or V: Data invalid.	
Mode		A=Autonomous, D=DGPS, E=DR (Only present in NMEA version 3.00).		
Checksum	*41			
<cr><lf></lf></cr>			Message terminator.	



\$GPGSA

This message transfers DOP and active satellites information. Following is an example.

\$GPGSA,A,3,07,02,26,27,09,04,15, , , , , ,1.8,1.0,1.5*33

The \$GPGSA message structure is shown below:

Field	Example	Unit	Notes
Message ID	\$GPGSA		GSA protocol header.
Mode	A		M: Manual, forced to operate in selected 2D or 3D mode. A: Automatic switching between modes.
Mode	3		 Fix not available. 2D position fix. 3D position fix.
Satellites Used (1)	07		SV on channel 1.
Satellites Used (1)	02		SV on channel 2.
Satellites Used (1)			SV on channel 12.
PDOP	1.8		
HDOP	1.0		
VDOP	1.5		
Checksum	*33		
<cr> <lf></lf></cr>			Message terminator.

(1) Satellites used in solution.



\$GPGSV

This message transfers information about satellites in view. The \$GPGSV message structure is shown below. Each record contains the information for up to 4 channels, allowing up to 12 satellites in view. In the final record of the sequence the unused channel fields are left blank with commas to indicate that a field has been omitted. Following is an example.

\$GPGSV,2,1,07,07,79,048,42,02,51,062,43,26,36,256,42,27,27,138,42*71 \$GPGSV,2,2,07,09,23,313,42,04,19,159,41,15,12,041,42*41

The \$GPGSV message structure is shown below:

Field	Example	Unit	Notes	
Message ID	\$GPGSV		GSA protocol header.	
Number of messages (1)	2		Number of messages, maximum 3.	
Message number	1		Sequence number, range 1 to 3.	
Satellites in view	07		Number of satellites currently in view.	
Satellite ID	07		Channel 1, ID range 1 to 32.	
Elevation	79	degree	Elevation of satellite, maximum 90.	
Azimuth	048	degree	Azimuth of satellite, range 0 to 359.	
SNR (C/N ₀)	42	dBHz	Range 0 to 99, null when not tracking.	
Satellite ID	02		Channel 2, ID range 1 to 32.	
Elevation	51	degree	Elevation of satellite, maximum 90.	
Azimuth	062	degree	Azimuth of satellite, range 0 to 359.	
SNR (C/N ₀)	43	dBHz	Range 0 to 99, null when not tracking.	
Satellite ID	26		Channel 3, ID range 1 to 32.	
Elevation	36	degree	Elevation of satellite, maximum 90.	
Azimuth	256	degree	Azimuth of satellite, range 0 to 359.	
SNR (C/N ₀)	42	dBHz	Range 0 to 99, null when not tracking.	
Satellite ID	27		Channel 4, ID range 1 to 32.	
Elevation	27	degree	Elevation of satellite, maximum 90.	
Azimuth	138	degree	Azimuth of satellite, range 0 to 359.	
SNR (C/N ₀)	42	dBHz	Range 0 to 99, null when not tracking.	
Checksum	*71			
<cr> <lf></lf></cr>			Message terminator.	

⁽¹⁾ Depending on the number of satellites tracked multiple messages of GSV data may be required.



\$GPMSS

This message transfers information about radio beacon signal-to-noise ratio, signal strength, frequency, etc. Following is an example.

\$GPMSS,55,27,318.0,100,1,*57

The \$GPMSS message format is shown below.

Field	Example	Unit	Notes
Message ID	sage ID \$GPMSS M		MSS protocol header.
Signal Strength	55	dB	SS of tracked frequency.
Signal-to-Noise Ratio	27 dB SNR of tracked frequency.		SNR of tracked frequency.
Beacon Frequency	318.0	kHz	Currently tracked frequency.
Beacon Bit Rate	100		Bits per second.
Channel Number (1)	1		The channel of the beacon being used if a multi-channel beacon receiver is used.
Checksum	*57		
<cr> <lf></lf></cr>			Message terminator.

(1) Fields marked in italic red apply only to NMEA version 2.3 (and later) in this NMEA message description.



\$GPRMC

This message transfers recommended minimum specific GNSS data. Following is an example.

\$GPRMC,161229.487,A,3723.2475,N,12158.3416,W,0.13,309.62,120598, ,*10

The \$GPRMC message format is shown below.

Field	Example	Unit	Notes	
Message ID	\$GPRMC		RMC protocol header.	
UTC Time	161229.487		hhmmss.sss	
Status	A		A: Data valid or V: Data invalid.	
Latitude	3723.2475		ddmm.mmmm	
N/S Indicator	N		N=north or S=south.	
Longitude	de 12158.3416 ddmm.mmm		ddmm.mmmm	
E/W indicator W			E=east or W=west.	
Speed over ground	0.13	knot	Speed over ground	
Course over ground	ourse over ground 309.62 degree Course over ground		Course over ground	
Date	120598		ddmmyy, current date.	
Magnetic variation (1)		degree	Not used.	
Mode (2)	A		A=Autonomous, D=DGPS, E=DR.	
Checksum	*10			
<cr> <lf></lf></cr>			Message terminator.	

⁽¹⁾ SiRF does not support magnetic declination. All "course over ground" data are geodetic WGS84 directions.

⁽²⁾ Fields marked in italic red apply only to NMEA version 2.3 (and later) in this NMEA message description.



\$GPVTG

This message transfers velocity, course over ground, and ground speed. Following is an example.

\$GPVTG,309.62,T,,M,0.13,N,0.2,K,A*23

The \$GPVTG message format is shown below.

Field	Example	Unit	Notes	
Message ID	\$GPVTG		VTG protocol header.	
Course (true)	309.62	degree	Measured heading	
Reference	Т		T = true heading	
Course (magnetic)		degree	Measured heading	
Reference (1)	M		M = magnetic heading (1)	
Speed	0.13	knot	Speed in knots	
Units	N		N = knots	
Speed	0.2	km/hr	Speed	
Units	K		K = km/hour.	
Mode (2)	A		A= $Autonomous, D$ = $DGPS, E$ = DR .	
Checksum	*23			
<cr> <lf></lf></cr>			Message terminator.	

⁽¹⁾ SiRF does not support magnetic declination. All "course over ground" data are geodetic WGS84 directions.

⁽²⁾ Fields marked in italic red apply only to NMEA version 2.3 (and later) in this NMEA message description.



\$GPZDA

This message transfers UTC Time and Date. Following is an example.

\$GPZDA,181813,14,10,2003,00,00*4F


The \$GPZDA message format is shown below.

Field	Example	Unit	Notes
Message ID	\$GPZDA		ZDA protocol header.
		Either using valid IONO/UTC or estimated from default leap seconds.	
UTC Day 14			01 to 31, day of month.
UTC Month	10	01 to 12.	
UTC Year	2003		1980 to 2079.
Local zone hours	00		Offset from UTC (set to 00).
Local zone minutes	00		Offset from UTC (set to 00).
Checksum	*4F		
<cr> <lf></lf></cr>			Message terminator.



附录:时区表

Time Zone Name	Coordinated Universal Time	Daylight Saving Time
Eniwetok, Kwajalein	-12	
Midway Island, Samoa	-11	
Hawaii	-10	
Alaska	-9	-8
Pacific Time (US and Canada); Tajuana	-8	-7
Mountain Time (US and Canada), Chihuahua, La Paz, Mazatlan, Arizona	-7	-6
Central Time (US and Canada), Saskatchewan, Guadalajara, Mexico City, Monterrey, Central America	-6	-5
Eastern Time (US and Canada), Indiana (East), Bogota, Lima, Quito	-5	-4
Atlantic Time (Canada), Caracas, La Paz, Santiago	-4	
Newfoundland	-3.5	-2.5
Brasilia, Buenos Aires, Georgetown, Greenland	-3	
Mid-Atlantic	-2	
Azores, Cape Verde Islands	-1	
Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London, Casablanca, Monrovia	+0	+1
Amsterdam, Belgrade, Bratislava, Budapest, Ljubljana, Prague, Sarajevo, Skopje, Warsaw, Zagreb, Brussels, Copenhagen, Madrid, Paris, Berlin, Bern, Rome, Stockholm, Vienna, West Central Africa	+1	+2
Athens, Istanbul, Minsk	+2	+3
Bucharest, Cairo, Pretoria, Jerusalem, Harare, Pretoria	+2	+3
Helsinki, Riga, Israel, Kyiv, Sofia, Tallinn, Vilnius	+2	+3
Baghdad, Kuwait, Riyadh, Nairobi	+3	+4
Moscow, St. Petersburg, Volgograd	+3	+4
Tehran	+3.5	+4.5





Time Zone Name	Coordinated Universal Time	Daylight Saving Time
Abu Dhabi, Muscat, Baku, Tbilisi, Yerevan	+4	
Kabul	+4.5	
Ekaterinburg, Islamabad, Karachi, Tashkent	+5	
Bombay, Calcutta, Madras, New Delhi, Chennai, Kolkata	+5.5	
Almaty, Dhaka, Colombo, Astana, Sri Jayawardenepura, Novosibirsk	+6	·
Bangkok, Hanoi, Jakarta, Krasnoyarsk	+7	
Beijing, Changqing, Hong Kong, Uramqi	+8	
Perth, Singapore, Taipei, Beijing, Chongqing, Hong Kong SAR, Kuala Lumpur, Irkutsk, Ulaan Bataar	+8	
Osaka, Sapporo, Tokyo	+9	
Seoul, Yakutks	+9	
Adelaide, Darwin	+9.5	
Brisbane, Guam, Port Moresby	+10	
Canberra, Melbourne, Sydney	+10	
Hobart, Vladivostok	+10	
Magadan, Solomon Islands, New Caledonia	+11	+12
Auckland, Wellington	+12	
Fiji Islands, Kamchatka, Marshall Islands	+12	

*Unit: hour

以上内容如有更新,以本公司最终版本为准,恕不另行通知! All Rights Reserved